



1994-2013 Dodge Ram 2500/3500 4WD
2005-2013 Dodge Ram 1500 Mega Cab 4WD
3.5" Front / 3" Rear Lift Kit
Part #1027

INSTALLATION SHEET

FRONT:

1. Park vehicle in a flat, level, and hard surface. Jack up the front end of the vehicle, support the vehicle with jack stands, the front wheels must be off the ground, and remove the front tires and wheels.
2. Disconnect the front sway upper end links.
3. Disconnect the brake line bracket from the axle housing.
4. Jack up the front axle to compress the coil spring.
5. Disconnect the upper and lower shock mounts
6. Repeat previous steps on the other side of the vehicle.
7. Lower down the axle so the coil springs will drop out.
8. Mark each coil to avoid reinstalling on the wrong side of vehicle.
9. Remove the upper spring isolators.
10. Install the urethane lift spacers on the same position the isolators were mounted and install the nuts provided with kits.
11. Position coil spring and shock absorbers back in the upper spring mounts and shock mounts.
12. Reinstall the upper shock mount.
13. Place the coil in the lower axle spring mount. Jack up the axle to install the lower shock bolts and nuts.
14. Lowering the jack holding the axle, allow the axle to full drop and make sure the coils do not come out.
15. Reinstall the sway bar end links and brake lines to the axle.
16. Remember to torque all bolts and nuts to factory specs. Reinstall tires and lower vehicle to the ground.

REAR:

1. Park vehicle in a flat, level, and hard surface. Chock the front wheels.
2. Jack up the rear end of the vehicle. Support vehicle with jack stand and remove rear wheels and tires.
3. Remove the emergency brake cable from the rear axle.
4. Remove the rear shocks from the axle mount to allow for the axle to drop.
5. Slightly support the axle at the center with a floor jack.
6. Remove the u-bolts from the vehicle.
7. Lower axle and install the block between the axle and leaf springs. Make sure that the narrower part of the block is facing towards the front.
8. Install the new longer u-bolts supplied with this kit.
9. Re-install the emergency brake line.
10. Re-install tires and wheels, remove jack stands, and lower vehicle.
11. Re-install shocks to the axle mount.



***The spacers included in this kit may not represent the actual lift you will achieve with any Performex™ Leveling or Lift kit.**
Example: A 2.5" Leveling Kit will have 1.25" inch spacers included. Due to independent suspension design on the vehicles, the lift will be approximately double the size of the actual spacer. For any questions please [Contact Us](#) for additional assistance.

WARNING

THIS VEHICLE HAS BEEN MODIFIED TO ENHANCE ITS OFFROAD PERFORMANCE. THE HANDLING WILL DEFFER FROM STANDARD PASSENGER CARS AND TRUCKS. DRIVE WITH CARE, REDUCE SPEED AND WEAR SEAT BELTS AT ALL TIMES.