



2004-2014 Chevy Colorado 4WD  
GMC Canyon 4WD  
2006-2014 Hummer H3 & H3T  
2.5" Leveling Kit  
Part #1033

## INSTALLATION SHEET

### STEP ONE:

1. Park vehicle in a flat, level and hard surface. Jack up the front end of the vehicle, support the vehicle with jack stands, the front wheels must be off the ground.
2. Remove the front tires and wheels.
3. Remove Torsion Adjuster bolt completely.
4. Place 1" sleeve spacer over stock adjuster bolt and reinstall. Bolt is located beneath the vehicle, midway front to back. There is one adjuster bolt on each side. One for each torsion bar.

### STEP TWO:

5. Install the shock extensions using supplied hardware. Note: shock extensions are not used on Chevrolet Colorado/ GMC Canyon
6. Reinstall tires and lower vehicle to the ground to set proper height.

### Special Note:

It is necessary to check and reset the proper ride height after test driving the vehicle. Failure to set the ride height correctly could cause premature CV joint, tie rod and ball joint wear. The correct ride height is measured from the center of the front wheel to the lower lip of the fender, and should be 24.25"



### WARNING

THIS VEHICLE HAS BEEN MODIFIED TO ENHANCE ITS OFFROAD PERFORMANCE. THE HANDLING WILL DEFFER FROM STANDARD PASSENGER CARS AND TRUCKS. DRIVE WITH CARE, REDUCE SPEED AND WEAR SEAT BELTS AT ALL TIMES.

\*The spacers included in this kit may not represent the actual lift you will achieve with any Performex™ Leveling or Lift kit. Example: A 2.5" Leveling Kit will have 1.25" inch spacers included. Due to independent suspension design on the vehicles, the lift will be approximately double the size of the actual spacer. For any questions please [Contact Us](#) for additional assistance.