



2004-2014 Chevy Colorado 4WD
GMC Canyon 4WD
2.5"Front / 1.5" Rear Lift Kit
Part #31040

INSTALLATION SHEET

STEP ONE:

1. Park vehicle in a flat, level and hard surface. Jack up the front end of the vehicle, support the vehicle with jack stands, the front wheels must be off the ground.
2. Remove the front tires and wheels.
3. Remove Torsion Adjuster bolt completely.
4. Place 1" sleeve spacer over stock adjuster bolt and reinstall. Bolt is located beneath the vehicle, midway front to back. There is one adjuster bolt on each side. One for each torsion bar.

STEP TWO:

1. Assemble both shackles included in this kit using two metal plates, one hex bolt, two flat washers, and the spacer between the two plates.
2. Chock the front wheels.
3. Jack up the rear end of the vehicle.
4. Support vehicle with jack stands.
5. Slightly support the axle at the center with a floor jack.
6. Remove the shackle at the rear of the leaf springs.
7. Install new shackle using hardware provided.
8. Jack up vehicle; remove jack stands, and lower vehicle to the ground.

Special Note:

It is necessary to check and reset the proper "FRONT" ride height after test driving the vehicle. Failure to set the ride height correctly could cause premature CV joint, tie rod and ball joint wear. The correct ride height is measured from the center of the front wheel to the lower lip of the front fender, and should be 24.25"



WARNING

THIS VEHICLE HAS BEEN MODIFIED TO ENHANCE ITS OFFROAD PERFORMANCE. THE HANDLING WILL DEFFER FROM STANDARD PASSENGER CARS AND TRUCKS. DRIVE WITH CARE, REDUCE SPEED AND WEAR SEAT BELTS AT ALL TIMES.

*The spacers included in this kit may not represent the actual lift you will achieve with any Performex™ Leveling or Lift kit. Example: A 2.5" Leveling Kit will have 1.25" inch spacers included. Due to independent suspension design on the vehicles, the lift will be approximately double the size of the actual spacer. For any questions please [Contact Us](#) for additional assistance.