



2007–2018 Chevy/GM  
Silverado, Avalanche, Tahoe  
2.5" Aluminum Leveling Kit  
Part #1034A

## INSTALLATION SHEET

1. Jack the front of the vehicle in accordance to manufacture recommendation and support with jack stands, so the front two tires are off the ground.
2. Remove the two front tires/wheels.
3. Disconnect the sway bar end links at the top and move sway bar out of the way.
4. Disconnect the brake line from the control arm.
5. Remove the 3 upper strut mounting nuts on the top off the strut tower.
6. Remove the lower strut bolts.
7. Separate the upper ball joint from the knuckle.
8. Remove the strut assembly from the vehicle.
9. Install the leveling kit on top of the strut assembly plate.
10. Secure the leveling kit using the previously removed upper strut nuts.
11. Install the strut assembly, and reinstall the lower bolts first.
12. Install the upper strut tower nuts.
13. Reinstall the brake line and lower ball joint.
14. Tighten the lower strut bolt and nut
15. Repeat steps 2 through 15 on other side of the vehicle.
16. After lift has been installed on both side check to see that all the bolts and nuts are torque to OEM specifications.



### WARNING

**THIS VEHICLE HAS BEEN MODIFIED TO ENHANCE ITS OFFROAD PERFORMANCE. THE HANDLING WILL DEFFER FROM STANDARD PASSENGER CARS AND TRUCKS. DRIVE WITH CARE, REDUCE SPEED AND WEAR SEAT BELTS AT ALL TIMES.**

**\*The spacers included in this kit may not represent the actual lift you will achieve with any Performex™ Leveling or Lift kit. Example: A 2.5" Leveling Kit will have 1.25" inch spacers included. Due to independent suspension design on the vehicles, the lift will be approximately double the size of the actual spacer. For any questions please [Contact Us](#) for additional assistance.**

**\*ATTENTION VALUED CUSTOMER\***

**For inquiries and replacement of missing parts please  
contact Performex™ directly for fast and convenient  
shipping direct to you.**

**Contact Us:**

**956-630-5438**

**[customerservice@performexweb.com](mailto:customerservice@performexweb.com)**