



2001-2018 Chevy/GM Suburban, Tahoe
Yukon, Avalanche 2WD/4WD
2" Rear Coil Spacer
Part #31041

INSTALLATION SHEET

1. Park vehicle in a flat, level and hard surface.
2. Loosen the lug nuts. Jack up the rear end of the vehicle, support the vehicle with jack stands, the rear wheels must be off the ground.
3. Remove the rear tires and wheels.
4. Unbolt the lower shock bolt.
5. Unbolt sway bar from the axle bracket.
6. Lower the rear axle.
7. The coils will be loose, but not enough to pull out.
8. Jack up one side of the axle forcing the other side to drop even closer to the ground.
9. Remove the coil.
10. Place spacer on top of the lower coil bucket.
11. Place coil back into place.
12. Repeat on opposite side.
13. Jack up vehicle from differential, align shocks, and reinstall bolts.
14. Reinstall sway bar bolts.
15. Install tires, check that all bolts and nuts are tight and lower vehicle to the ground.
16. It is recommended that the vehicle be aligned after installing this kit.



WARNING

THIS VEHICLE HAS BEEN MODIFIED TO ENHANCE ITS OFFROAD PERFORMANCE. THE HANDLING WILL DEFFER FROM STANDARD PASSENGER CARS AND TRUCKS. DRIVE WITH CARE, REDUCE SPEED AND WEAR SEAT BELTS AT ALL TIMES.

***The spacers included in this kit may not represent the actual lift you will achieve with any Performex™ Leveling or Lift kit. Example: A 2.5" Leveling Kit will have 1.25" inch spacers included. Due to independent suspension design on the vehicles, the lift will be approximately double the size of the actual spacer. For any questions please [Contact Us](#) for additional assistance.**

ATTENTION VALUED CUSTOMER

**For inquiries and replacement of missing parts please
contact Performex™ directly for fast and convenient
shipping direct to you.**

Contact Us:

956-630-5438

customerservice@performexweb.com