



2005-2018 Ford F250/F350/F450 4WD
2.5" Leveling Kit
Part #1011

INSTALLATION SHEET

1. Park vehicle in a flat, level, and hard surface. Jack up the front end of the vehicle, support the vehicle with jack stands, the front wheels must be off the ground.
2. Remove the front tires and wheels
3. Raise the axle using the floor jacks enough to relieve tension in the shocks.
4. Disconnect end links to sway bar,
5. Remove the bolt at the brake line bracket to avoid damaging when lowering the axle.
6. Remove shocks on both sides.
7. Lower the front axle as far as possible. Mark each spring left or right, and up or down to reinstall later on the same position and orientation. Remove only one spring at a time.
8. Compress spring down, install coils spacer and reinstall spring.
9. Repeat steps 7 and 8 for on the other side of the vehicle.
10. Lift axle back up.
11. Reinstall brake line bracket
12. Reconnect sway bar end links.
13. Torque all nuts and bolts to factory specifications.
14. Put wheels back on and lower vehicle to ground.
15. It is recommended that the vehicle be aligned after installing this kit.



WARNING

THIS VEHICLE HAS BEEN MODIFIED TO ENHANCE ITS OFFROAD PERFORMANCE. THE HANDLING WILL DEFFER FROM STANDARD PASSENGER CARS AND TRUCKS. DRIVE WITH CARE, REDUCE SPEED AND WEAR SEAT BELTS AT ALL TIMES.

*The spacers included in this kit may not represent the actual lift you will achieve with any Performex™ Leveling or Lift kit. Example: A 2.5" Leveling Kit will have 1.25" inch spacers included. Due to independent suspension design on the vehicles, the lift will be approximately double the size of the actual spacer. For any questions please [Contact Us](#) for additional assistance.

ATTENTION VALUED CUSTOMER

**For inquiries and replacement of missing parts please
contact Performex™ directly for fast and convenient
shipping direct to you.**

Contact Us:

956-630-5438

customerservice@performexweb.com