



Torsion Keyway Install

INSTALLATION SHEET

1. Park the vehicle on a flat, level and hard surface. Jack up the front end of the vehicle and support the vehicle with jack stands. The front wheels must be off of the ground.
2. Using an unloading tool or 2 jawed puller release the tension on the adjusting bolt.
3. Remove the bolt and threaded block from the cross member.
4. Release the tension on the keyway.
5. Slide the torsion bar forward and remove the keyway. It is needed to remove the cross member.
6. Install the new keyway and slide the torsion bar into position.
7. Tension the new keyway with the unloading tool.
8. Reinstall the threaded block and bolt.
9. Repeat for the other side.
10. Adjust the bolts so that the truck sits level at the desired height.
11. Remove the jack stands and lower the vehicle.



WARNING

THIS VEHICLE HAS BEEN MODIFIED TO ENHANCE ITS OFFROAD PERFORMANCE. THE HANDLING WILL DEFFER FROM STANDARD PASSENGER CARS AND TRUCKS. DRIVE WITH CARE, REDUCE SPEED AND WEAR SEAT BELTS AT ALL TIMES.

ATTENTION VALUED CUSTOMER

For inquiries and replacement of missing parts please contact Performex™ directly for fast and convenient shipping direct to you.

Contact Us:

956-630-5438

customerservice@performexweb.com