



2007-2018 Toyota Tundra / Sequoia
2" Aluminum Leveling Kit
Part #1042A

INSTALLATION SHEET

1. Park the vehicle on a flat, level and hard surface. Jack up the front end of the vehicle and support the vehicle with jack stands. The front wheels must be off of the ground.
2. Remove the front tires and wheels.
3. Disconnect the front sway bar lower end links.
4. Loosen the two inner lower control arm pivot bolts. **Do not remove the bolt.**
5. Using a floor jack and placing it under the lower control arm, support the arm and remove the upper strut nuts. Remove the lower strut bolt and nut.
6. Remove the lower ball joint bolts and lower the control arm. Then remove the strut assembly.
7. Install the leveling kit on top of the strut assembly plate and secure it with the upper strut nuts previously removed.
8. Reinstall the strut assembly with the spacer installed onto the truck. Screw the 4 upper strut nuts on to hold the strut in place.
9. Raise the lower control arm and install the lower strut bolt and nut.
10. Install the lower ball joint bolts back into the control arm and knuckle assembly. Torque to factory specs.
11. Tighten the upper strut nuts and the lower strut bolt and nut. Torque to factory specs.
12. Tighten the inner lower control arm bolts and torque to factory specs.
13. Repeat steps 3 through 12 on the other side of vehicle.
14. Reinstall the tires and wheels. Jack up the truck and remove the jack stands.
15. With the truck on the ground install the sway bar end-link.
16. Check that all bolts and nuts are installed and tightened.
17. It is recommended that the vehicle be aligned after installing this kit.



WARNING

THIS VEHICLE HAS BEEN MODIFIED TO ENHANCE ITS OFFROAD PERFORMANCE. THE HANDLING WILL DEFFER FROM STANDARD PASSENGER CARS AND TRUCKS. DRIVE WITH CARE, REDUCE SPEED AND WEAR SEAT BELTS AT ALL TIMES.

***The spacers included in this kit may not represent the actual lift you will achieve with any Performex™ Leveling or Lift kit. Example: A 2.5" Leveling Kit will have 1.25" inch spacers included. Due to independent suspension design on the vehicles, the lift will be approximately double the size of the actual spacer. For any questions please [Contact Us](#) for additional assistance.**

ATTENTION VALUED CUSTOMER

**For inquiries and replacement of missing parts please
contact Performex™ directly for fast and convenient
shipping direct to you.**

Contact Us:

956-630-5438

customerservice@performexweb.com