



1994-2013 Dodge Ram 2500/3500 4WD
1994-2001 Dodge Ram 1500 4WD
2005-2012 Dodge Ram 1500 Mega Cab 4WD
2.5" Leveling Kit
Part #1022

INSTALLATION SHEET

1. Park vehicle in a flat, level, and hard surface.
2. Jack up the front end of the vehicle, support the vehicle with jack stands, the front wheels must be off the ground
3. Remove the front tires and wheels.
4. Disconnect the front sway upper end links.
5. Disconnect the brake line bracket from the axle housing.
6. Jack up the front axle to compress the coil spring.
7. Disconnect the upper and lower shock mounts
8. Repeat previous steps on the other side of the vehicle.
9. Lower down the axle so the coil springs will drop out.
10. Mark each coil to avoid reinstalling on the wrong side of vehicle.
11. Remove the upper spring isolators.
12. Install the urethane lift spacers on the same position the isolators were mounted and install the nuts provided with kits.
13. Position coil spring and shock absorbers back in the upper spring mounts and shock mounts.
14. Reinstall the upper shock mount.
15. Place the coil in the lower axle spring mount. Jack up the axle to install the lower shock bolts and nuts.
16. Lowering the jack holding the axle, allow the axle to full drop and make sure the coils do not come out.
17. Reinstall the sway bar end links and brake lines to the axle.
18. Remember to torque all bolts and nuts to factory specs. Reinstall tires and lower vehicle to the ground.
19. It is recommended that the vehicle be aligned after installing this kit.



WARNING

THIS VEHICLE HAS BEEN MODIFIED TO ENHANCE ITS OFFROAD PERFORMANCE. THE HANDLING WILL DEFFER FROM STANDARD PASSENGER CARS AND TRUCKS. DRIVE WITH CARE, REDUCE SPEED AND WEAR SEAT BELTS AT ALL TIMES.

***The spacers included in this kit may not represent the actual lift you will achieve with any Performex™ Leveling or Lift kit. Example: A 2.5" Leveling Kit will have 1.25" inch spacers included. Due to independent suspension design on the vehicles, the lift will be approximately double the size of the actual spacer. For any questions please [Contact Us](#) for additional assistance.**